

PR-P03E

+12B	1
+12B	2
Wiegand 0	3
Wiegand 1	4
RS-485(-B)	5
RS-485(+A)	6
RS-232(RX)	7
RS-232(TX)	8
RS-232(DTR)	9
RS-232(DSR)	10
RS-232(RTS)	11
Свободный	12
GND	13
GND	14